



Typical DIY underwater Acrylic housing back plate seal design fabricated with a table saw. Cut the  $\frac{1}{4}$ " plexi for a close slip fit into the housing and slightly round sharp corners to prevent O-ring damage.