

(o) Sandpaper lightly the edges of suit hood where old gasket was attached, and the strapping for new gasket.

(e) Spread a thin film of rubber cement on



Figure 2-26. Lightweight diving outfit.

each sanded surface and allow to dry until tacky. Repeat for two or three coats.

(d) As the last application of cement becomes tacky, press new gasket firmly into position on the hood. If marks left by removal of old gasket are followed, accurately, the fit will be perfect.

(e) Cement old binding tape (or facsimile cut from patching cloth) over the seam. Allow to dry overnight before use.

(7) As stated before, the principle of operation of the lightweight equipment is based on the elimination of air from the dress. In order to dispose of any air in the dress, an exhaust



Figure 2-27. Rifle cartridge belt.



Figure 2-28. Leather weighted belt.