

## DELTA 4 SECOND STAGE

Dia. No.	Part #	Description	Dia. No.	Part #	Description
1c	6949.23	RING, COVER (METAL)	22b	4969	WASHER, SNAP
	6930.07	RING, COVER (BK)	<b>23a</b>	<b>2.004</b>	<b>O-RING, BALANCE SHAFT</b>
2c	6931.07	COVER, FRONT (BK)	24c	5245	TUBE, ADJUSTMENT
	6931.18	COVER, FRONT (YL)	25b	2.016	O-RING, ADJUSTMENT TUBE
3b	6932.11	COVER, INNER FRONT (BL)	26c	4971	PAD, SPRING
	6932.18	COVER, INNER FRONT (YL)	27c	4589	SPRING, ADJUSTMENT
	6932.34	COVER, INNER FRONT (BK)	28c	6684	FOLLOWER, PISTON SPRING
4b	5236	DIAPHRAGM	29c	6685	SHAFT, ADJUSTMENT
5c	5248.07	ASSEMBLY, HOUSING	30b	2.107	O-RING, STEM
6c	5234.07	COVER, EXHAUST	31b	5054	WASHER, THRUST
7b	6326	VALVE, EXHAUST	32c	6332	NUT, PACKING
<b>8a</b>	<b>1978.07</b>	<b>WRAP, TIE</b>	33c	6971.18	KNOB, ADJUSTMENT (BK/YL)
9b	4485.07	MOUTHPIECE		6971.29	KNOB, ADJUSTMENT (BK/GY)
<b>10a</b>	<b>2.010</b>	<b>O-RING, ORIFICE</b>	34c	4787.2	SCREW, ADJUSTMENT KNOB (BK)
11c	6621	ORIFICE	35c	6924	SWITCH, VENTURI
12c	6956	COUPLING, SWIVEL	36b	2.009	O-RING, VENTURI SWITCH
13b	3.906	O-RING, COUPLING	37b	5251	RING, SWITCH RETAINING
<b>14a</b>	<b>4340</b>	<b>SEAT, POPPET</b>	38c	40.2120.030	ASSEMBLY, SWIVEL HOSE (BK)
15c	4333	POPPET	<b>39a</b>	<b>6959</b>	<b>WASHER, LP HOSE</b>
16c	4593	SPRING, POPPET	<b>40a</b>	<b>6968</b>	<b>O-RING, LP HOSE</b>
17c	5254	ARM, LEVER			
<b>18a</b>	<b>5117</b>	<b>WASHER</b>	N/S	3.903	O-RING, LP HOSE (First Stage End)
19b	4335	SPACER			
<b>20a</b>	<b>4336</b>	<b>NUT, LOCK</b>	N/S	40.6162	KIT, SERVICE PARTS (includes all <b>Bold</b> items)
21c	5244	SHAFT, BALANCE			

