



#	Part #	Description
	BKH01	SERVICE KIT, HIGHLAND INFLATOR
	TL126	HIGHLAND INFLATOR TOOL
	BPH30	HIGHLAND INFLATOR 19" AIRWAY COMPLETE (COARSE THREAD)
	HL205	HIGHLAND INFLATOR - LOWER UNIT
1.	BPH22	CORRUGATED OVAL HOSE 1" ID x 19" LENGTH
2.	BPH18	CABLE PIN
3.	BPH06	ORAL SEAT
4.	<b>BPH05</b>	<b>O-RING FOR ORAL SEAT</b>
5.	BPH08	QD NIPPLE
6.	<b>BPH07</b>	<b>O-RING</b>
7.	BPH09	POWER SEAT
8.	<b>BPH10</b>	<b>O-RING</b>
9.	<b>BPH12</b>	<b>O-RING</b>
10.	BPH14	VALVE HOUSING
11.	<b>BPH13</b>	<b>O-RING</b>
12.	BPH15	POWER SPRING
13.	BPH16	POWER BUTTON & STEM ASSY.
14.	BPH20	POWER SHAFT COMPLETE-FIELD SERVICE
15.	BPH17	MOUTHPIECE
16.	BPH04	PLUG
17.	BPH03	ORAL INFLATOR SPRING
18.	BPH01	ORAL BUTTON (BLACK) AND STEM ASSEMBLY
19.	BPH21	ELBOW
20.	BPH26	COLLAR NUT - COARSE THREAD (CURRENT)
	BPH25	COLLAR NUT - FINE THREAD (OLDER STYLE)
21.	BP632	RUBBER GASKET, GRAY - FOR MANIFOLD W/COARSE THREADS
	BP08	RUBBER GASKET, BLACK - FOR MANIFOLD W/FINE THREADS

Part numbers in bold italics are standard replacement parts

