



## Push the **Red Button** to message boats within 4000 Sq. miles!

- Lift the red flap and press for 3 seconds to increase range 2.5 x and send alert message & your gps position to every ship around you.



## **Green Button**

“Talk to your own boat or buddy.”


- Press Green Button to turn Lifeline on.
- Press & hold until “T” appears on LCD screen, then talk into mic.
- Release Green Button to receive.



## **Orange Button**

“Call every boat around you on CH16.”

- Press & hold until “T” appears on LCD screen, then talk into mic.











**IMPORTANT!** Ensure that O-ring and USB cap are always clean and free of contaminants.



## HOW TO USE RADIO, GPS & RED BUTTON







### **GREEN BUTTON**

- Changing Green Button Channel
  1. Press Green Button 3 times quickly to enter channel change mode.   
  2. Scroll through channels using Green Button. 
  3. Hold down Green Button to select and confirm channel. 
- Turn on Position Indicating Light
  1. Press Green Button 2 times quickly to turn position indicating light on.  
  1. Press Green Button one more time to turn light off. 



### **ORANGE BUTTON**

- **SELF DIAGNOSTIC TEST**  
(test unit before all dive trips)
  1. Press Orange Button 3 times quickly to start self-diagnostic test.   
  2. Press Orange Button once after test complete to exit menu mode. 



### **RED BUTTON**

Use to automatically transmit alert message and your GPS position to all nearby modern marine radios.

**EMERGENCY USE ONLY.** There may be severe penalties for improper use.




1. Press once to turn Lifeline on, press again and hold for 5 seconds until LCD screen reads “DISTRESS MODE ON”.

Note: The alert message will not transmit until you have GPS lock onto screen. For maximum range, hold Lifeline as high above the water line as possible.

2. Once initiated, the alert message, your MMSI number and your GPS coordinates will be sent out at timed intervals for a minimum of 24 hours.
3. To turn off, press and hold until LCD screen reads “DISTRESS MODE OFF”.

**IMPORTANT!** Please refer to Owner's Manual to perform testing of this function.  
 Visit: [www.nautiluslifeline.com/support](http://www.nautiluslifeline.com/support)



## LIFELINE CONTROLS



### IMPORTANT!

- Red Button Emergency is not functional until unit is MMSI registered and activated.
- The watertight integrity of the unit depends on the protective USB cover being in place.

## LCD SCREEN VIEW



- Splash proof in all sea conditions, when upper cap is open.
- Non-emergency functions will automatically shut off after 5 minutes of inactivity.

## MAINTENANCE & STORAGE

- Ensure that your orange O-ring and USB cap are always perfectly clean and free of contaminants.
- Always store LifeLine in a dry place, out of direct sunlight, with cap open and antenna fully extended.
- Gently rinse your LifeLine in fresh water after each use.
- Do not pressure blow-dry.
- Do not remove antenna. Removal of antenna will void warranty and may result in damage to your LifeLine.
- Charge your LifeLine and perform self-diagnostic test before any dive trip or weekend of diving.

