



維修教學影片
Introduction Video



scuba-aquatec.com

NO.	ITEM NO.	DESCRIPTION	QTY
1	0111	YOKE KNOB ASSEMBLY 鉤口旋鈕主件	1
2	0055	3500 PSI YOKE 鉤口3500PSI 旋轉環系統	1
3	0133	YOKE RETAINER 鉤口固定環	1
4	0113	FILTER 過濾器	1
5	2-011-02	O-RING O型環	1
6	0118	DUST CAP 防塵蓋	1
7	0119	STYLE DISK 馬鞍	1
8	0221	MAIN HOUSING 本體	1
9	0229	LIFTER 螺桿	1
10	0206	DIAPHRAGM 橫隔膜	1
11	0207	DIAPHRAGM WASHER 橫隔膜墊片	1
12	0208	SPRING SEAT 彈簧座	1
13	0209	SPRING WASHER 彈簧墊片	2
14	0210	MAIN SPRING 本體中蓋彈簧	1
15	0212	ADJUST SCREW 可調整螺帽	1
16	0213	HP SEAT 高壓墊片	1
17	0215	BALANCE SPRING 平衡式彈簧	1
18	2-006-02	O-RING O型環	1
19	2-011-02	O-RING O型環	1
20	2-016-01	O-RING O型環	1
21	0228	BALANCE PLUG 本體尾端螺帽	1
22	3-904-01	O-RING O型環	2
23	0108	HP PLUG 高壓孔螺帽	2
24	3-903-01	O-RING O型環	3
25	0109	LP PLUG 低壓孔螺帽	3
26	0114	DIN HOUSING 釘口主體	1
27	0116	DIN WHEEL KNOB ASSEMBLY 釘口旋轉環	1
28	2-012-02	O-RING O型環	1
29	0115	DIN RETAINER 釘口固定環	1
30	2-112-02	O-RING O型環	1
31	0225	DIAPHRAGM PISTON 橫隔膜座	1
32	0223	TRANS PISTON 活塞	1
33	0226	SILICONE DISK 矽膠墊片	1
34	0227	ENV CAP 本體尾端蓋	1